

ACHI® IR-PRO-SC



BGA Rework Station

User Manual



- **""Safety Instrouctions**

- I. **Electric Safety**

- II. **Operation Safety**

- III. **The operation and conservation condition of products**

- **Our contact information**

- **product guarantee and so on**

- **The parameters of **IR-PRO-SC** BGA Rework Station**

- **hardware description and Self-help install**

- **Set Bottom Temperature Controller**

- **Programmer/Controller General Description**

- **BGA Rework operation steps**

- **Prompt**

Safety Instructions

I. Electrical safety

- Make sure the supply power voltage accord with the standards 220V-250V/50hz alternating current before installing.
- To avoid possible electric shock caused serious damage, please disconnect the power cord from the outlet temporary before moving machines .
- If the machine damages,please contact us for maintenance.If the damage caused by the users when they dismantle or repair independently,they should take on the loss by themselves.

II. Operating safety

- Please carefully read the relevant information provided by the manual before starting using this product .
- Make sure the power cord has been properly connected properly before using the products.
- Installed the equipment in stable work platform to use,where the air mobility should be small as possible.Avoid it closing to air conditioners,fans and the other outlet.
- In case of electrical short-circuit,avoid the products contacting with water.
- Forbid using this equipment in flammable and explosive substances.
- The operators' hands or other parts of the body should maintain a safe distance from the heater.Forbid touching the heater to avoid scalding.
- If you have any technical questions or suggestions in the course of using this product,please contact with our technology department.We will try our best to solve.

III.Environmental requirements of operation and conservation

1. Operation environment of products

- Operation temperature:15 ~ 45 °C
- Operation humidity:5% to 95%, non-condensing
- Products should be kept in the air mobility of a smaller environment under the welding operation.

2.Conservation environment of products

- Storage temperature:-20 ~ 70 °C
- Storage humidity: 5% to 95%, non-condensing

The parameters of IR-PRO BGA Rework Station


Basic Parameters	
Heating	Upper Dark IR / Bottom IR
Dimension	L 475mm×W480mm×H420 mm
Weight	27kg
Total weight	About 29 kg, vary with the differen need of the users
Electrical Parameters	
Power	220V AC
Upper Heating	Dark IR
Size of Upper heating	80mm×80mm
Consumption of upper heating	400W
Bottom Heating	IR
Size of Bottom heating	260 mm×245 mm
Consumption of Bottom heating	2000W
General power	2500W
Temperature Control	
Control mode of Upper	PLC programmable logic controller, precision ± 0.5%, Alarm
Control mode of Bottom	Independent temperature control, high-precision closed-loop control, precision ± 0.5%, NO Alarm
Rework Function	
SMD	Suit for welding,remove or repair packaged devices such as BGA,PBGA,CSP,multi-layer substrates, EMI metallic shield product and solder/lead free Rework 、welding
Size of applicable chips	≤70mm×70 mm
Size of applicable PCB	≤400mm×305 mm

Hardware description


ACHI® IR-PRO-SC BGA Rework Station is composed of upper part of Heating Components / Bottom Preheat Module / PCB Table / Temperature Control Parts !
 Temperature control Table is control the upper and lower heating ,Can Simultaneously heated or First preheat ,then the upper part of heating.



1. Upper Heater
2. X-axis Regulator
3. LED Auxiliary Lighting
4. Y-axis Lifting Regulator
5. Bottom Heater (Pre-Heater)
6. PCB Table and locking handle seat
7. Cooling Fan
8. Start button
9. Emergency Stop button
10. Cooling switch
11. Lighting switch
12. Upper Fan switch
13. Bottom Temperature Controller
14. Upper Programmable Temperature Controller



switch selector for Bottom Heater Module



PCB Table



Fixed pole for Shaped Board

Set Bottom Temperature Controller

PV: Display window of actual temperature.

SV: Display window of setting temperature.



Press the **SET** button of Bottom temperature control instrumentation for 1 seconds, then the **PV** window to show **SU**.



The **SV** window to show current setting temperature, And the adjustable number flashes. Press key **^** **v** to adjust temperature,, Press key **<** to modify the value.




After the setted , Press the **SET** button for 1 seconds, save the current temp.



Programmer/Controller General Description

The programmable controller contains an in-built setpoint generator in addition to the controller function. This setpoint generator can produce a temperature/time profile with 10*16 segments (0~9, 10 Sets of Curves). When the program is running, the current setpoint from the setpoint generator is fed to the control algorithm. The current setpoint is continuously shown on the lower display.

The sixteen segments are defined in the order: Ramp 1, Dwell period 1, Ramp 2, Dwell period 2..., and are executed in succession.



S.N.	Item	Functions
①		Parameters setting key
		(Up key) Increase value
		(Down key) Decrease value
②		Selects the program pattern number
		Starts/hold the program, changes the mode from fixed value control to program control
		Program parameters setup
		Changes the indication on SV/MV/TIME display
③	OUNT	Output indicator
④	STEP	Indicates the step number of program
⑤	PRO	(Program monitor indicator) During program control, ‘/’ is lit when the PV is rising During program control, ‘-’ is lit when the PV is constant During program control, ‘\’ is lit when the PV is falling
⑥	PTN	(Pattern number display) Indicates the pattern number ‘0~9’
⑦	RUN	(Program control running indicator)

		The LED indicator is lit during program control
⑧	PV	(PV Display) Indicates the Process/Measured value
⑨	SV	It is lit when the Setting Value(SV) is being displayed on the lower display
⑩	TIME MV SV	(SV/MV/TIME display) It indicates the Setting Value(SV), Manipulating Value(MV), or Time(TIME) (The display content can be changed by the 'DISP/SELECT' key)
⑪	AL1	It is lit when the Alarm1 output is 'ON'
	COM	(Communication indicator) It flashes when the controller is in active communication with a host computer

● Program Parameters Setting

Ramp Rate1: r_i

A ramp consists of a slope(linear gradient) and a target setpoint. The control setpoint increases or decreases at a linear ramp rate from the actual measured value until a specified target setpoint is reached. The relative positions of the actual measured value and the target setpoint determine whether the slope of the ramp is positive or negative. Parameters R1, R2, R3... express the ramping rate in unites per minute(0.01~99.99), parameters L1, L2, L3... the appropriate target setpoint in display units.

If R1 = END, the program will be ended when the program runs to the slope.

Target Setpoint 1: U_i

The target value to which the setpoint ramps when the programmer has been placed into RVN.

Dwell period 1:

In a Dwell period, the target setpoint, which has been attained, remains unchanged for a fixed period. All the dwell periods are defined by their duration in minutes with parameters D1, D2, D3...(0~9999). When the program is running, these parameter display the time remaining in the active dwell period. If the parameter equals zero, the dwell period is skipped.





When the controller runs in the PV displaying status:

- 1). Select the target program pattern number with the PTN/ key.
- 2). press SET/PROG key, the first program parameter appears in the upper display. The value associated with this parameter will be shown in the lower display.
- 3). Use ▲ and ▼ key to modify the value.
- 4). Press the PAR/SET key, the next parameter appears. At the same time, the modification has been saved in the memory. Use ▲ and ▼ key to modify the value.

Repeat this procedure till all the parameters are set. Or if there is no key operation within 16 seconds, the menu times out automatically.

Program Parameter List

S.N.	Mnemonic	Parameter	Adjustable Range
1	r1	Ramp Rate 1	1
2	l1	Target Setpoint 1	0~230、End
3	d1	Dwell Time 1	0~9999sec
4	r2	Ramp Rate 2	1
5	l2	Target Setpoint 2	0~230、End
6	d2	Dwell Time 2	0~9999sec
...
	Hb		230



Program Examples


Rework Operation Steps

1、Be all set


① Fixed motherboard



② Shift sensor , sensor press close to BGA chip.



③ Adjust the height of heating head with adjustment knob (Prompt: BGA chip in the middle of heating head , heating head away from BGA chip \geq 2CM.)



2、Start heating

- Select the appropriate temperature program segment,




- then press the start switch. In the operation can press the Emergency stop switch, stop operating!



- 3、 After the program runs, automatic Alarm (8 SECONDS) , and automatically cut off the heating power, this time you can check the following solder ball is completely liquefied, BGA chips should be subject to settlement, floating state .





3、Heating completed

- 1、Moving Heating head and Sensor ,open the Upper fan and Cooling Fan Switch
- 2、Remove motherboard , Clear insulating tape !
- 3、BGA Rework Station Cooled ,Then close Total Power !

Warning:

- If BGA Rework Station NO Cooling , Do not close the Power !
- When the temperature is not cooled, Do not touch heating module!

Prompt

- 1、 Installed the equipment in stable work platform to use where the air mobility should be small as possible .Avoid it closing to air conditioners, fans and the other outlet.
- 2、 **ACHI® IR-PRO-SC** Rework Station sensor Direct contact with motherboard, So Temperature display is Actual temperature。
- 3、 In order to avoid damage to the motherboard capacitor, so use insulation tape please , Maintenance completed ,then Removal of insulation tape , So as to avoid short-circuit !
- 4、 After removal of BGA chip , PCB Bonding Pad Need to clean up , Avoid cold solder joint See BGA chip tin completely liquefied, Then To move the BGA chip, So as to avoid Bonding Pad Damage !
- 5、 BGA chips should be subject to settlement, floating state Prohibited in all solder ball did not fully liquefied, by force if removal of chips, so as to avoid pad off, chip or motherboard scrap!
- 6、 To improve success rate of Rework , PCB and chips need drying and processing in principle, PCB board or chip moist heat process will occur in the burst phenomenon, the Rework process may hear the blasting sound of a minor。 According to actual situation Please, self-control.
- 7、 PCB board heating time is too long or repeated several times the surface heating will lead to discoloration.
- 8、 Users from modifying temperature parameters, Please use scrap PCB tested, Heating whole time about 10 seconds before the end of solder balls should be fully liquefied, f the liquefaction advanced or delayed, ! Should be regulating up/down the temperature setting. So as to avoid heat damage to chips or low-temperature sealing-off。
- 9、 The factory equipped with two sets of programmable temperature control table used parameters:

PTN-1: Lead Rework

PTN-2: Lead-Free Rework

Rework temperature curve to set examples					
Lead : Sn63Pb37					
PTN- 1					
r1	1	L1	85	d1	75
r2	1	L2	150	d2	40
r3	1	L3	185	d3	45
r4	END				
Lead-Free:					
Sn96.5Ag3Cu0.5					
PTN- 2					
r1	1	L1	85	d1	60
r2	1	L2	140	d2	45
r3	1	L3	170	d3	25
r4	1	L4	220	d4	40
r5	END				